

The logo for 'FUZZ RANGERS' features a circular emblem on the left containing a five-pointed star with a dot in the center, surrounded by a grid of lines. To the right of the emblem, the word 'FUZZ' is written in a bold, black, blocky font. Below 'FUZZ', the word 'RANGERS' is written in a large, white, outlined font with a double-line border.

CONTROLLI:

«FUZZ»

Manopola Level: Controlla il Volume di Uscita

Manopola Fuzz: Regola La Quantità di Fuzz

«BOOST»

SwitchEQ: **MID** >fa passare le medio basse frequenze
HI >fa passare le alte frequenze
LOW >fa passare tutta la banda di frequenze

Manopola BOOST: Regola il Gain del transistor, da pulito a crunch a overdrive.

-Switch invertitore: **F>B** Il fuzz entra nel boost

In questa posizione il boost aumenta il Volume del Fuzz e ne Regola le frequenze tramite lo switchEQ

B>F Il boost entra nel fuzz

In Questa Posizione il boost aumenta il gain del Fuzz e "taglia" le frequenze tramite lo switchEQ

Specifiche Tecniche:

INPUT: a destra del pedale

OUTPUT: a sinistra del pedale

DC: Il Connettore di alimentazione si trova sul pannello posteriore del pedale
la polarità è STANDARD tipo BOSS(tm) con il tip negativo

Alimentazione: 9V DC

Assorbimento totale: 6mA

Misure: 122x67x39mm L P H